


Mounting should only be attempted by a qualified ski technician with an understanding of how ski crampons function.

### Installing Pressure Plate

In order to install the pressure plate you need to drill a hole in the spring housing. As you can see from the picture below this hole will be approximately centered in the underside of the spring housing. The best way to locate the spot to drill is by inserting the plastic pressure plate as far inside as it will go. Mark the location of the hole either with a pen or by lightly marking the spot with a drill - **do not drill through with the pressure plate in place**. Remove the pressure plate and then drill through the bottom portion of the spring housing assembly using a 9/64 to 5/32" (3.6 to 3.9MM) drill bit.

After the hole is drilled reinsert the pressure plate and affix it with the #6/32 flat head screw provided.



Hole for pressure plate

### Installing Crampon


Slide crampon into mount block from right side with crampon in a position 90 degrees from horizontal. Holding crampon as close to centerline of pivot pin will help provide easy entry and installation. Stop will limit travel to operating position. Allow crampon to rotate down to horizontal position which locks it in its lateral position. Make sure crampon is allowed to drop down parallel to ski prior to applying pressure with boot. This will avoid damage to base and crampon.

Questions regarding installation and operation, and any suggestions may be addressed to:

B & D Precision– [www.bndskigear.com](http://www.bndskigear.com)  
19818 Canpom Ct.  
Redding , CA 96003

Ski mountaineering is an exceptionally hazardous activity which often results in severe injuries and death. Any person purchasing or using this equipment assumes the responsibility for seeking proper training in its use and also assumes all risk for injury or damage sustained while using any of this equipment. This equipment is not to be used for any other purpose other than what it is intended for. Failure to follow these warnings increase the risk of injury or death. B & D Precision is not or shall not be liable for direct, indirect, incidental or other types of damages arising out of, or resulting from the use of this product.


Spring housing with pressure plate fully installed.



Toe Bar

### Installing Mount Block

Mounting block should be centered on a **FLAT** surface far enough from the back of the toe piece in order to clear the toe bar (approx. 1MM). Drill screw holes with 5/32 (3.9MM) drill



Crampon